

Level Dry Replacement Parts

Electrical Components

Part #	Description
630A-001A	Control Box 1 Phase
630B-001A	Control Box 3 Phase
632-223A	Winch, Deluxe, Mounted
632-220A	Black Winch w/Cord
423-330-001A	Winch Protection Kit
423-331-001A	Winch Motor Replac. Kit
630-016A	Grain Proximity Switch
E-6192	Slack & Max fill Switch
H-1883	Spring for Slack Switch
E-5287	Switch, On
E-5100	Switch, Off
E-5287	Switch, Manual Up
E-5287	Switch, Manual Down
E-6171	Switch, Safety Shutoff (Rotary)
E-5006-01	Switch, Mode
E-6203	Breaker, 4 Amp
E-6225	Breaker, 6 Amp
E-6204	Bridge Rectifier
E-5458	Fuse, 2 Amp, Fast Blow
E-6143	Relay, Power
E-5764	Relay, Grain Sense
E-6126	Relay, Up or Down
E-6152	Starter, 1 Phase, 5Hp
E-5727	Overload Heater, 5Hp
E-6125	Switch, Aux. N.C.
E-6269	Switch, Aux. N.C.(97-Current)
E-5611	Starter, 1 Phase, 7.5Hp
E-5729	Overload Heater, 7.5Hp
E-5612	Starter, 3 Phase
E-5726	Overload Heater, 5Hp
E-5727	Overload Heater, 7.5Hp
E-6136	Timer, Delay 0.1-8 Min.
E-6128	Timer, Up 0.25-5 Sec
E-6131	Light, Indicator
E-6141	AC Amp Meter, 0-80 Amp
E-6224	Resistor, 2 OHM, 50 Watt
632-168P	Slip Ring, Commutator (6)
632-175A	Slip Ring, Brush Assy. Set

Parts & Assemblies

Part #	Description
Augers	
631G-001A	Standard, 94 1/2" 5.5 x 6
631H-001A	Standard, 36" 5.5 x 6
631I-001A	Hi-Cap 94 1/2" 7 x 7
631J-001A	Hi-Cap 36" 7 x 7
Misc Parts	
D-3226	Coupler Chain
D-3576	Sprocket 1 1/8" Bore
D-3577	Sprocket 1 3/8" Bore
632-150P	Key, 5/16" x 1"
234-002P	Key, 1/4" x 1"
632-170P	Alum. Shear Key 1/4" x 1"
632-216P	Gearbox
631-038A	Bearing, Carrier Assy.
D-3578	Bearing, Flangette
D-3533	Bearing, Slip Ring Carriage (4)
632-110A	Pulley Assy, Dual, Bin Roof
632-111A	Pulley Block, Winch
632-112A	Pulley, Lift Assy.
632-113A	Pulley, Leveler
632-027A	Puley Assy, C.V. Top
H-2054	Ring, Brush 6" Wisker
H-2053	Ring, Brush 8" Wisker
631-034P	Brass Washer
F-1797	E Clip for Brass Washer
Accessories	
634F-001A	Anti-Bury Kit
632-191A	Safety Lock Kit
634G-001A	Parts Box
460G-005P	Tube 8" x 17' 8 5/8"